

Defender Rear Bumper, Polaris General™ Instructions

hmfracing.com/equipment/polaris-general/defender-rear-bumper-polaris-general/installation

Installation


1. Install the (4) M8 carriage bolts, washers and nuts and bolt the rear bumper under the dump bed.



2. Align the Rear Bumper and tighten.


Discussion

Hardware

-  (4) Bolt - Carriage - M8-1.25 X 20

-  (4) Nut - Nylock - M8-1.25

-  (4) NUT - NY100K - M18-1.25

-  (4) Washer - Flat - 1/4"

* Click thumbnails to enlarge

© Copyright 2020, HMF Engineering • 5111 West 164th Street • Brookpark, Ohio 44142

[terms](#) [privacy](#) 