


PLEASE READ INSTRUCTIONS CAREFULLY BEFORE INSTALLATION



**PRODUCT INCLUDES:**


- (1) 13" MIRROR/17" MIRROR
- (1) MOUNTING BRACKET
- INSTALLATION HARDWARE



INSTALL THE MIRROR TO THE MOUNTING BRACKET WITH THE 4 INCLUDED SCREWS.



INSERT THE BALL HEAD SCREW FIRST, FOLLOWED BY THE RUBBER BALL HEAD CAP. MAKE SURE THE BALL HEAD JOINT IS COVERED BY THE BALL HEAD CAP, THEN SCREW IN THE SOCKET SCREW. TIGHTEN THE SCREW TO SECURE THE MIRROR'S PLACEMENT.



OPEN THE C-CLAMP AND PLACE ON TO YOUR CAGE, IN YOUR DESIRED LOCATION AND ANGLE. THEN CLOSE AND TIGHTEN DOWN TO LOCK IN PLACE.

